


# ExpressPod EP02 Small Assembly Instructions

## BEFORE YOU START

Identify an appropriate location for your AirLink. The higher you can place it, the wider an area it will be able to cover. It also needs access to a power outlet.

- 1 On the AirLink:  
**A red LED lights steadily:** the AirLink has power.  
**A Green LED starts blinking:** it is establishing an Internet Connection.  
**Green LED remains steady:** it has connected.

- 2 If the AirLink has failed to connect within ten minutes, try moving it to a location with better reception.



- 3 Once the AirLink is showing a **steady green LED**, it is ready to be tested with your ExpressPods.

- 4 Place your ExpressPods where you intend to use them.  
Press a button on each one and look for a green LED and a beep sound. This indicates the ExpressPod is within range of the AirLink.



To get started,  
please visit:  
**[guide.ombea.com](https://guide.ombea.com)**.

